

defunc<sup>®</sup>  
SIMPLIFYING YOUR CHOICE<sup>®</sup>



YOUR DEFUNC BLUETOOTH<sup>®</sup> MANUAL



**EN:** Thank you for choosing the DeFunc Bluetooth®. DeFunc® is all about simplicity. 4 models, 4 colors, 4 user styles. The Defunc Bluetooth® is based on the Hybrid to enable a “multi-function” use of the Bluetooth®.

**KEY DATA:**

BLUETOOTH® 4.1.

WIRELESS OPERATING RANGE UP TO 10M

BATTERY OPERATING/TALK TIME 3-4H, STANDBY TIME UP TO 80 H



### GETTING CONNECTED IN THREE EASY STEPS

- 1) Connect the Bluetooth® by holding down the PLAY/PAUSE (1) for 5 seconds. You should hear 2 separate prompts and the Bluetooth® LED (2) will start to flash in Red and Blue.
  - 2) Switch on the Bluetooth® on your mobile phone or other device and find and connect to “Defunc BT”
  - 3) As you connect you should hear a short prompt and the red light (2) on your Bluetooth® stops flashing. Your mobile or other device will indicate that you are connected.
- For trouble shooting please see [www.de-func.com/troubleshooting](http://www.de-func.com/troubleshooting).

*Enjoy*

YOUR DEFUNC BLUETOOTH®

### USING THE DEFUNC BLUETOOTH®

Press ⏻ (1) for 3-4 seconds until you hear one prompt to turn on the Bluetooth®. (If you also need to connect the Bluetooth® please follow the steps on the previous page)

Press ⏻ (1) to answer or hang up a call or to Play and Pause the music

Press + (3) One time to increase the volume.

Hold down ⏻ (3) to Forward to the next track

Press - (4) One time to lower the volume

Hold down ⏪ (4) to Rewind to the previous track

Press ⏻ (1) for 3-4 seconds until you hear one prompt to turn off the Bluetooth®.

For optimal user experience fix the Bluetooth® device on your chest and speak into the mic (5) on the Bluetooth® device. Note that the Bluetooth® connection can be interfered if there are other wireless devices nearby.

**CAUTION** Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type

The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.




#### Environmentally friendly disposal

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

**FR: Nous vous remercions d'avoir choisi le produit DeFunc Bluetooth®. DeFunc® simplifie vos choix: 4 modèles, 4 couleurs, 4 styles. Le DeFunc Bluetooth® est un modèle de type Hybride qui permet une utilisation «multifonction» du Bluetooth®.**

#### CARACTÉRISTIQUES IMPORTANTES:

BLUETOOTH® 4.1.  
FONCTIONNE SANS FIL DANS UN RAYON JUSQU'À 10M  
AUTONOMIE DE LA BATTERIE / EN CONVERSATION 3-4H, EN VEILLE JUSQU'À 80 H



- 1) Connectez le Bluetooth® en maintenant enfoncée la touche PLAY / PAUSE (1) pendant 5 secondes. Vous allez entendre 2 sons distincts et le voyant Bluetooth va se mettre à clignoter en rouge et bleu (2).
- 2) Allumez le Bluetooth® sur votre téléphone portable ou autre appareil et recherchez et connectez-vous à "Defunc BT".
- 3) Lorsque la connexion s'établit vous allez entendre un son et la lumière rouge (2) du voyant Bluetooth va cesser de clignoter. Votre appareil mobile ou autre appareil va vous indiquer que vous êtes connecté.

Pour le dépannage merci de vous rendre sur [www.de-func.com/troubleshooting](http://www.de-func.com/troubleshooting)

**Enjoy**  
YOUR DEFUNC BLUETOOTH®

## UTILISATION DU DEFUNC BLUETOOTH®

Appuyez sur (1) pendant 3-4 secondes pour allumer le Bluetooth®. Vous allez entendre 1 son distinct (Si vous devez également connecter le Bluetooth merci de suivre les étapes indiquées ci-dessus)  
Appuyez sur (1) pour répondre ou raccrocher à un appel ou pour lire et mettre en pause la musique.  
Appuyez une fois sur (3) pour augmenter le volume.  
Maintenez appuyer sur (3) pour passer à la piste suivante  
Appuyez une fois sur (4) pour baisser le volume  
Maintenez appuyer sur (4) pour revenir à la piste précédente  
Pour une expérience optimale d'utilisation fixez le module Bluetooth® sur votre poitrine et communiquez via le micro (5) situé sur le module Bluetooth®. Notez que la connexion Bluetooth® peut être perturbée s'il y a d'autres appareils sans fil sont à proximité.

**CAUTION** Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type

The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



#### Environmentally friendly disposal

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

**EN:** このたびは、ディファンクBluetooth®を選んでいただき誠に有難うございます。ディファンクはシンプルさが全てです。4つのモデル、4つのカラー、そして4つのユーザースタイルだけです。

ディファンクBluetooth®は、Bluetooth®の多機能な使用用途を可能にするハイブリッド製品です。

KEYデータ BLUETOOTH® 4.1.

ワイヤレスオペレーティングレンジ 10Mまで

バッテリー稼働時間 使用時間3~4時間 待機時間80時間まで



では、お楽しみください!

ディファンクBLUETOOTH®



接続するための3つの簡単なステップ

- 1) PLAY/PAUSEボタン①を5秒間押すと2回シグナル音がして、Bluetooth®のLED②が赤と青で点滅し始めます。
  - 2) 貴方の携帯電話あるいは他の機器のスイッチを入れると、ディファンクBluetooth®が接続します。
  - 3) 接続すると短いシグナル音がし、貴方のBluetooth®の赤い光が点滅を停止します。貴方の携帯電話あるいは他の機器が接続したことを示しています。
- 何か不具合が生じた場合は、次のURLをご覧ください。[www.de-func.com/troubleshooting](http://www.de-func.com/troubleshooting).

*Enjoy*

YOUR DEFUNC BLUETOOTH®

**ディファンクBLUETOOTH®の使い方**

シグナル音がするまで、Ⓜ(1)を3~4秒間押すことで、BLUETOOTH®がオンになります。

(BLUETOOTH®の接

続がまだ必要な場合は、前記のステップをおこなってください)

Ⓜ(1)を押すと、電話にでたり、通話を切ったり、あるいは音楽のスタートや一時停止ができます。

Ⓜ(3)を一度押すと音量が上がります。Ⓜ(3)を押したままにすると次のトラックに進みます。

Ⓜ(4)を一度押すと音量が下がります。Ⓜ(4)を押したままにすると前のトラックに戻ります。

快適なユーザー体験を得るためには、BLUETOOTH®装置をあなたの胸に取り付けてください、そして、BLUETOOTH®装置のマイク⑤に話してください。

近くに別のワイヤレス機器がある場合、BLUETOOTH®接続の妨げになることがあります。

**CAUTION** Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type

The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: [1] this device may not cause harmful interference, and [2] this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



**Environmentally friendly disposal**

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.



[www.de-func.com](http://www.de-func.com)

**THE ART OF UTILITY AB**  
SE559005911801  
Danderydsgatan 28  
114 26 STOCKHOLM  
SWEDEN

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Art of Utility AB is under license. Other trademarks and trade names are those of their respective owners.